



PER USO INTERNO
FOR INTERNAL USE




Cod.1615

la RACCHETTA

Pratica racchetta elettronica a tripla rete per eliminare con una scarica elettrica mosche, zanzare ed altri insetti volanti in completa sicurezza e pulizia, senza schiacciarli, senza sporcare le pareti e senza utilizzare prodotti chimici. La rete elettrificata interna a maglie strette riesce ad eliminare anche gli insetti più piccoli, mentre le reti protettive esterne prevengono contatti accidentali con le mani. Dotata di luce per uso notturno. E' ideale per la casa, in campeggio, al mare.

Electronic mosquito swatter with triple net to eliminate flies, mosquitoes and other flying insects using electric shock. It is completely safe and clean, without squashing the insects, dirtying walls and without using chemical products. The inner electrified net with close links manages to also eliminate smaller insects while the protective outer nets protect against accidental hand contact. Equipped with lamp for night use. It is ideal at home, camping and by the sea.



MODALITA D'USO

- Inserire le batterie (2 pile LR6 1,5V) nell'apposita sede.
- Mettere l'interruttore in posizione ON (posizione centrale).
- Tenere premuto il pulsante rosso di attivazione (indicata anche dal LED acceso) e colpire l'insetto volante che al contatto con la rete elettrificata resta fulminato.
- In caso di scarsa luminosità posizionare l'interruttore in posizione ON + LAMPADA per accendere la lampada e procedere come sopra.
- Riportare l'interruttore in posizione OFF al termine dell'uso per salvaguardare la carica delle batterie.

Quando il pulsante rosso è premuto la rete metallica interna è elettrificata ed è consigliabile evitare il contatto diretto con il corpo. Il prodotto è provvisto di condensatore a scarica veloce che estingue la carica elettrica sulla rete metallica dopo il rilascio del pulsante di attivazione.

AVVERTENZE

Utilizzare il prodotto in conformità alle norme CEI vigenti per gli impianti elettrici. Il prodotto è destinato all'utilizzo in luoghi asciutti e non polverosi; non utilizzare il prodotto in fienili, stalle e locali simili e ambienti a presenza di vapore infiammabile o polveri esplosive. Per ambienti particolari usare prodotti specifici.

IL PRODOTTO NON È UN GIOCATTOLO. TENERE LONTANO DAI BAMBINI.
UTILIZZARE IL PRODOTTO ESCLUSIVAMENTE PER GLI USI INDICATI.

I bambini non devono giocare con l'apparecchio. L'apparecchio non deve essere usato da bambini o da persone con ridotte capacità fisiche, sensoriali o mentali o prive di esperienza o della necessaria conoscenza. La pulizia e la manutenzione destinata ad essere effettuata dall'utilizzatore non deve essere effettuata da bambini. Spegner l'apparecchio e togliere le batterie prima di pulire l'apparecchio. Utilizzare un pennellino asciutto a setole morbide per rimuovere gli eventuali residui di insetti dalla rete. Per la pulizia delle altre parti, utilizzare un panno morbido e asciutto. Non utilizzare acqua o altri liquidi per evitare cortocircuiti.

Complimenti, avete acquistato un prodotto elettrico sicuro e di qualità. Questo prodotto, come tutti quelli del nostro assortimento, è realizzato a regola d'arte nel rispetto delle norme applicabili e, se usato correttamente, non può arrecare danno a persone, animali domestici o cose.

INFORMAZIONE AGLI UTENTI

Informazione agli utenti: ai sensi dell'art. 26 del Decreto Legislativo 14 marzo 2014, n. 49 "Attuazione della direttiva 2012/19/UE sui rifiuti di apparecchiature elettriche ed elettroniche (RAEE)" Il simbolo del cassonetto barrato riportato sull'apparecchiatura o sulla sua confezione indica che il prodotto alla fine della propria vita utile deve essere raccolto separatamente dagli altri rifiuti. L'utente dovrà, pertanto, conferire l'apparecchiatura giunta a fine vita agli idonei centri comunali di raccolta differenziata dei rifiuti elettrotecnici ed elettronici. In alternativa alla gestione autonoma è possibile consegnare l'apparecchiatura che si desidera smaltire al rivenditore, al momento dell'acquisto di una nuova apparecchiatura di tipo equivalente. Presso i rivenditori di prodotti elettronici con superficie di vendita di almeno 400 m² è inoltre possibile consegnare gratuitamente, senza obbligo di acquisto, i prodotti elettronici da smaltire con dimensioni inferiori a 25 cm. L'adeguata raccolta differenziata per l'avvio successivo dell'apparecchiatura dismessa al riciclaggio, al trattamento e allo smaltimento ambientalmente compatibile contribuisce ad evitare possibili effetti negativi sull'ambiente e sulla salute e favorisce il reimpiego e/o riciclo dei materiali di cui è composta l'apparecchiatura.

INSTRUCTION

- Place the batteries (2 batteries LR6 1,5V) in the specific compartment.
- Place the switch in the ON position (central position).
- Keep the red activation button pressed (indicated by the active LED) and strike flying insects, which on contact with the electrified net will be electrocuted.
- In case of poor light, position the switch in the ON + LAMP position to access the lamp and proceed as above.
- Turn the switch OFF at the end of use to keep the battery charged.

When the red button is pressed, the inner metal net is electrified and you are advised to avoid direct contact with your body. The product has a fast shock capacitor that extinguishes the electric charge on the metal mesh after the activation button is released.

WARNING

Use the product in compliance with CEI standards in force on electrical systems. The product is intended for use in dry and dust-free locations: do not use the product in hay sheds, stables and similar premises in the presence of inflammable vapours or explosive powders. For particular environments use specific products.

THE PRODUCT IS NOT A TOY. KEEP AWAY FROM CHILDREN.
USE THE PRODUCT ONLY FOR ITS INTENDED USE.

Children must not play with the appliance. The appliance must not be used by children or people with reduced physical, sensory or mental capacity or without experience or the necessary know-how. Cleaning and maintenance to be carried out by the user must not be carried out by children. Switch off the appliance and remove the batteries before cleaning it. Use a small, dry, soft bristle brush to remove any insect residue on the net. To clean other parts, use a soft, dry cloth. Do not use water or other liquids to avoid short circuits.

Congratulations! You have purchased a safe, quality electrical product.

This product, as with all our range, is manufactured to standard and in compliance with the applicable standards and, if used correctly, does not cause harm to people, pets or property.

USER INFORMATION

Information for users: pursuant to Art. 26 of Legislative Decree 14 March 2014, no. 49 "Implementation of Directive 2012/19/EU on electrical and electronic waste equipment (WEEE)" The symbol of the crossed bin on the equipment or on the packaging indicates the product at the end of its useful life must be collected separately from other waste. The user should therefore give the appliance, which is no longer usable, to suitable municipal differentiated waste collection centres for electrotechnical and electronic waste. Alternatively, autonomous management is possible by delivering the appliance you want to dispose of to the retailer when purchasing a new, equivalent appliance.

Electronic retailers with retail surfaces of at least 400 m² can also accept electronic products for disposal with dimensions under 25 cm free of charge, without you being obliged to make a purchase. Appropriate differentiated collection and subsequent sending of the equipment for recycling, processing and disposal, using environmentally compatible means, contributes to avoiding possible negative effects on the environment and health and promotes re-use and recycling of materials used to manufacture the equipment.

MADE IN CHINA



AIUTA LA RACCOLTA DIFFERENZIATA
Questa confezione è in polipropilene.
Va smaltita nella:
RACCOLTA PLASTICA



Via Sottocorna, 21/B PARRE (BG) Italy
Tel. 035703244 - www.polypool.it